
Check a Load in four steps


Your numbers make the estimate; the result is not an authorization.

1 · Open




Open Check a Load. With no profile yet, go to the truck profile first.

2 · Profile




Copy the vehicle ratings and the tank, and set your fuel economy and reserve once. Save the truck profile.

3 · Six questions



One at a time: pay, ratings, where the load is (optional), miles, fuel, costs. Review, then Calculate.

4 · Result



The estimate opens at the top. Use See calculation details for every row. At your first trip start RSL asks once for your 2 or 3 letters; each trip then gets a number like 261003-JA-01.

The ratings do not verify compatibility or change the estimate. Actual weight may remain unknown. Route miles are a car estimate, not a truck route. No license or route-restriction check exists.